



Operator Maintenance

Contact Support

DAILY

MAINTENANCE REMINDERS



Clean wire mesh of entry and exit conveyors



Maintain steel conveyor with scraper



Clean entry and exit conveyor crumb trays



Keep the oven clean



Visually inspect the oven

WEEKLY



Clean both main conveyor crumb trays

MONTHLY



Lubricate both main conveyor chains with lubricant F075 0050 found in semi-annual maintenance kit T00000610

EVERY 6 MONTHS



Contact your local service company for maintenance and have kit T00000610 on hand

EVERY 12 MONTHS



Contact your local service company for maintenance and have kit T00000611 on hand



MAINTENANCE REMINDERS





Operator Maintenance

Contact Support





Clean wire mesh of entry and exit conveyors



Maintain stone conveyor with scraper



Clean entry and exit conveyor crumb trays



Keep the oven clean



Visually inspect the oven

WEEKLY



Clean both main conveyor crumb trays

MONTHLY



Lubricate both main conveyor chains with lubricant F075 0050 found in semi-annual maintenance kit T00000610

EVERY 6 MONTHS



Contact your local service company for maintenance and have kit T00000610 on hand

EVERY 12 MONTHS



Contact your local service company for maintenance and have kit T00000611 on hand



MAINTENANCE REMINDERS





Operator Maintenance

Contact Support





Clean wire mesh of entry and exit conveyors



Maintain steel conveyor with scraper



Clean entry and exit conveyor crumb trays



Keep the oven clean



Visually inspect the oven

WEEKLY



Clean both main conveyor crumb trays

MONTHLY



Lubricate both main conveyor chains with lubricant F075 0050 found in semi-annual maintenance kit T00000610

EVERY 6 MONTHS



Contact your local service company for maintenance and have kit T00000610 on hand

EVERY 12 MONTHS



Contact your local service company for maintenance and have kit T00000611 on hand