


A crumb tray that is incorrectly inserted can cause temperature issues.



Air infiltration inside the oven must be avoided.

A crumb tray that is properly inserted is snug against the front of the oven, as well as under the oven.

