

Hot Rocks Classic GEN 3 GUIDE HOW TO DETERMINE PLC CONTROLLER FIRMWARE VERSION FOR PROPER PROGRAM COMPATIBILITY CHOICE.

1. Remove rear panels
2. Locate the PLC controller
3. Remove din rail stopper on the right PLC side
4. Note the FW version number
5. Choose the proper compatible software as per firmware version
 - 3.020 for PLC Firmware 12.011 & HMI Firmware 5.011
 - 3.0201 for PLC Firmware 14.011 & HMI Firmware 6.011
 - 3.0202 for PLC Firmware 23.011 & HMI Firmware 8.012

