



The cooling fan is located at the rear of the oven. Start the oven to see if there is air flow.



If no air flow, turn OFF the oven with the switch on the side. Remove the back panel in front of the cooling fan. Be careful with the fan wires.



- Verify if the cooling fan is unplug. It's the connector in the red circle.
- Verify if something preventing rotation.
- Reassemble the back panels.