



To access the settings:



Press the settings button on the bottom left corner of the main screen.




Now press , it will prompt a login screen



**Enter the following credentials (all caps):**


**User = SYSTEM**

**Password = SYSTEM**




**Press on the Padlock to confirm (1), then the home to go back to the main screen (2)**

Now you may press on the wrench again (bottom right) and press on the “Param” option



This time you will be taken to the following screen:



Select Machine. On the next screen you will find the setting that controls direction, simply press on it

